

Serviços de Rede Local

Prof: Jefferson Brandão





Acesse o sistema com seu login.

```
Debian GNU/Linux 9 debian tty1
debian login: aluno
Password:
Last login: Wed May 19 13:25:49 –03 2021 on tty1
inux debian 4.9.0–15–amd64 #1 SMP Debian 4.9.258–1 (2021–03–08) x86_64
The programs included with the Debian GNU/Linux system are free software;
the exact distribution terms for each program are described in the
individual files in /usr/share/doc/*/copyright.
Debian GNU/Linux comes with ABSOLUTELY NO WARRANTY, to the extent
permitted by applicable law.
aluno@debian:~$
```



Para realizar a configuração, vamos alterar para o usuário root.

aluno@debian:\$su

```
Debian GNU/Linux 9 debian tty1
debian login: aluno
assword:
Last login: Wed May 19 13:25:49 –03 2021 on tty1
Linux debian 4.9.0–15–amd64 #1 SMP Debian 4.9.258–1 (2021–03–08) x86_64
The programs included with the Debian GNU/Linux system are free software;
the exact distribution terms for each program are described in the
individual files in /usr/share/doc/*/copyright.
Debian GNU/Linux comes with ABSOLUTELY NO WARRANTY, to the extent
permitted by applicable law.
aluno@debian:~$ su
root@debian:/home/aluno# _
```



Vamos instalar o servidor Apache.

root@debian:/home/aluno#apt install apache2

Insira o DVD1 do Debian e pressione <ENTER>

Após a instalação, verifique o estado do servidor Apache

root@debian:/home/aluno#systemctl status apache2



Gerenciando o servidor:

Parar servidor: root@debian:/home/aluno#systemctl stop apache2

Iniciar o servidor: root@debian:/home/aluno#systemctl start apache2

Reiniciar o servidor: root@debian:/home/aluno#systemctl restart apache2



Gerenciando o servidor:

Recarregar o servidor, sem quedas de conexão: root@debian:/home/aluno#systemctl reload apache2

Desativar o servidor no boot: root@debian:/home/aluno#systemctl disable apache2

Ativar o servidor no boot: root@debian:/home/aluno#systemctl enable apache2



Vamos criar a estrutura para nossa página web:

root@debian:/home/aluno#mkdir -p
/var/www/turma.com/html

Alterando a propriedade da pasta: root@debian:/home/aluno#chown -R \$USER:\$USER /var/www/turma.com/html

root@debian:/home/aluno#chmod -R 755 /var/www/turma.com



Criando a página:

root@debian:/home/aluno#nano
/var/www/turma.com/html/index.html

```
<html>
    <head>
        <title>Bem-vindo a Turma!</title>
    </head>
    <body>
        <h1>Intranet da turma!</h1>
        </body>
    </html>
```





Vamos alterar as diretivas de host virtual:

```
root@debian:/home/aluno#nano/etc/apache2/sites-available/turma.com.conf
```



Vamos alterar as diretivas de host virtual:



Vamos habilitar o arquivo:

root@debian/home/aluno#a2ensite turma.com.conf

Desabilitando o site padrão: root@debian/home/aluno#a2dissite 000-default.conf

Reiniciando o Apache: root@debian/home/aluno#systemctl restart apache2



